



Conspicuity Inc.
400 Travis Lane #30
Waukesha, WI 53189
(877) 411-8551
info@conspicuityinc.com
www.conspicuityinc.com

DOING BUSINESS
WITH BIKERS
FOR 28 YEARS!

CARE INSTRUCTIONS FOR VESTS AND STICK-ON PRODUCTS

Thank you for selecting these beautiful, reflective and almost indestructible stick-on products. Products have a one year manufacturer's warrantee for defects in workmanship.

Application of stick-ons

Stick-ons will adhere to any hard, clean surface. Cleaning is best done using denatured alcohol, which will remove waxes, dirt, grease, fingerprints, etc. and evaporate leaving no residue. It is especially important to thoroughly clean NEW helmets etc, which often come from the factory with a protective coating that prevents adhesives from sticking.

Surface should be dry and warm (above 50 degrees Fahrenheit). In cool weather, warm surface with a hair dryer.

For flat surfaces, simply position product, then press firmly into place. For contoured surfaces, warm the stick-ons using a hair dryer for a better fit. Excess stretching of the product adversely affects adhesion and may destroy the integrity of the material. Cutting product allows moisture to enter, destroying reflectivity.

Suggested uses for stick-ons

Cars and trucks: outside and inside of trunk, edges of doors, tailgate.

Motorcycles: fenders, fairings, hard bags, windscreens, helmets.

Bicycles: fenders, helmets.

Home uses: Mailbox, fences, driveway markers, edges for steps, ceiling/joists/doorways
Light switches, wheelchairs. Sports uses: running shoes, roller blades, ski poles, sleds & wagons

Cleaning

Road film and bugs may be removed by placing on a flat surface, washing with a soft cloth or sponge and a mild detergent solution, and rinsing with water. Do not dry clean or place in washing machine. Hang vest to dry.

Storing

Store garments on hangers, separating the fluorescent and non-fluorescent colors. If it is necessary to fold the material (though folding is not the recommended storage method), separate the folded surfaces with plain paper or cloth, *to prevent fluorescent tapes from bleeding onto other tapes when in extended close contact*. Store unused product, separating the different colors with paper or cloth. Avoid extreme heat.

Most of all: Enjoy your high quality Conspicuity Inc. Product!